



## **❖** Operating Instructions

- Turn on kettle heat switch.
- Turn on kettle motor switch.
- Turn on exhaust switch.
- Open the popcorn packet and squeeze the contents into the kettle.
- When popcorn has popped, turn handle down to dump popcorn.
- Repeat cycle until the desired amount of popcorn has been reached.
- On the final batch of popcorn, turn the kettle heat switch when the popcorn breaks the top of the lid. This prevents the kettle from burning and smoking.
- Turn off all switches after complete.

## Cleaning Instructions

- Allow kettle to cool until warm enough to handle.
- Unplug kettle and remove from machine.
- ❖ Wipe kettle, kettle lids, crossbar and exterior clean.
- ❖ Do not immerse kettle in water!!!
- Remove popped corns.
- Remove the "old maid" pan; empty un-popped kernels and wipe clean.
- Wipe interior of machine clean.
- Return the machine clean to the rental center to avoid cleaning charges.

## **❖** Helpful Hints

- ❖ Do not touch kettle while operating. It is very hot!!!
- ❖ Air vents must be unobstructed to allow for proper air flow.